

# Teldio Radio Compatibility

Application	Feature	Control Station Models	User Radio Models	Notes
<b>RBX +Plus</b>	Talkgroup Calls	XPR 4000 Series XPR 5000/5000e Series	All MotoTRBO Radio Models <sup>1</sup>	Works in Digital and Analog Modes. <sup>1</sup> requires TX interrupt feature to allow talkback from radios
	Private Calls / Callgroup Calls	XPR 4000 Series XPR 5000/5000e Series	SL 7550 / SL7550e SL 7580 / SL7580e XPR 7550 / XPR 7550IS / XPR 7550e XPR 7580 / XPR 7580IS / XPR 7580e XPR 6550 / XPR 6580 <sup>1</sup> XPR 4000 Series <sup>1,2</sup> XPR 5000/5000e Series <sup>2</sup>	<sup>1</sup> requires Motorola Option Board (part # PMLN5496AS) <sup>2</sup> requires keypad accessory
<b>R2R</b>	Talkgroup Conversation Recording	XPR 4000 Series XPR 5000/5000e Series	All MotoTRBO Radio Models All DMR Standard Radios	Works in Digital and Analog Modes.
<b>MDN</b>	Man Down Detection	XPR 5000/5000e Series	XPR 7550 / XPR 7550IS / XPR 7550e XPR 7580 / XPR 7580IS / XPR 7580e XPR 6550 / XPR 6580 <sup>1</sup> XPR 4000 Series <sup>1,2</sup> XPR 5000/5000e Series <sup>2</sup> XPR 7350 / XPR 7350e <sup>3</sup> XPR 7580 / XPR 7580e <sup>3</sup>	<sup>1</sup> requires Motorola Option Board (part # PMLN5496AS) <sup>2</sup> requires keypad accessory <sup>3</sup> some functionality limited
<b>Gateway Applications (AMS/LW)</b>	Audio Alerts Notifications	XPR 5000/5000e Series	All MotoTRBO Radio Models All DMR Standard Radios	Works in Digital and Analog Modes.
	Text Messages	XPR 5000/5000e Series	SL 7550 / SL7550e SL 7580 / SL7580e XPR 7550 / XPR 7550IS / XPR 7550e XPR 7580 / XPR 7580IS / XPR 7580e XPR 3500/XPR 3500e XPR 6550 / XPR 6580 XPR 4000 Series <sup>2</sup> XPR 5000/5000e Series <sup>2</sup>	<sup>2</sup> requires keypad accessory

# Teldio Radio Compatibility

<b>TruFleet</b>	GPS Tracking	XPR 4000 Series XPR 5000/5000e Series	All GPS Compatible Radio Models	
<b>TruDispatch Console</b>	Private/Group Calls	XPR 4000 Series XPR 5000/5000e Series	All MotoTRBO Radio Models	
	Text Messages/Page	XPR 4000 Series XPR 5000/5000e Series	SL 7550 / SL7550e SL 7580 / SL7580e XPR 7550 / XPR 7550IS / XPR 7550e XPR 7580 / XPR 7580IS / XPR 7580e XPR 6550 / XPR 6580 XPR 4000 Series <sup>2</sup> XPR 5000/5000e Series <sup>2</sup>	<sup>2</sup> requires keypad accessory